KETTLER

Assembly Manual Cross-Trainer "MONDEO"

Item # 07852-690



Thank you for purchasing our high quality KETTLER product. If you have any questions or concerns regarding this product, please contact us:

KETTLER International, Inc. Parts & Service Department P.O.Box 2747 Virginia Beach, Virginia 23450 USA E-mail parts@KETTLERUSA.COM Tel: 757-427-2400 ext. 81 Fax: 757-563-9273

Please have this owner's manual with you when you call.

DO NOT CONTACT YOUR RETAILER.



FREIZEIT MARKE KETTLER

USA

Important Instructions

Please read these instructions carefully prior to carrying out assembly and using for the first time. They contain information which is important for your safety as well as for the use and maintenance of the appliance. Keep these instructions in a safe place for reference purposes, maintenance work and to assist you when ordering spare parts.

For Your Safety

- The crosstrainer should be used only for its intended purpose, i.e. for physical exercise by adult persons.
- Any other use of the equipment is prohibited and may be dangerous. The manufacturer cannot be held liable for damage or injury caused by improper use of the equipment.
- The crosstrainer has been designed in accordance with the latest standards of safety. Any features which may have been a possible cause of injury have been avoided or made as safe as possible.
- Incorrect repairs and structural modifications (e.g. removal or replacement of original parts) may endanger the safety of the user.
- Damaged components may endanger your safety or reduce the lifetime of the equipment. For this reason, worn or damaged parts should be replaced immediately and the equipment taken out of use until this has been done. Use only original KETTLER spare parts.
- If the equipment is in regular use, check all its components thoroughly every 1 -2 months. Pay particular attention to the tightness of bolts and nuts. This is particularly true for the attachment of grip strap, running plate and fastening of the

handlebar and front tube.

- To ensure that the safety level is kept to the highest possible standard, determined by its construction, this product should be serviced regulary (once a year) by specialist retailers.
- Instruct persons using the equipment (in particular children) on possible sources of danger during exercising.
- Before beginning your program of exercise, consult your doctor to ensure that you are fit enough to use the equipment. Base your program of exercise on the advice given by your doctor. Incorrect or excessive exercise may damage your health!
- Any interference with parts of the product that are not described within the manual may cause damage, or endanger the person using this machine. Extensive repairs must only be carried out by KETTLER service staff or qualified personnel trained by KETTLER.
- In case of enquiry, please contact your KETTLER dealer.
- In choosing the location of the apparatus, ensure a sufficient safety distance from any obstacles. The apparatus must not be mounted in the immediate vicinity of main passageways (paths, doorways, corridors).

Handling the equipment

- Before using the equipment for exercise, check carefully to ensure that it has been correctly assembled.
- Before beginning your first training session, familiarize yourself thoroughly with all the functions and settings of the unit.
- It is not recommended to use or store the apparatus in a damp room as this may cause it to rust. Please ensure that no part of the machine comes in contact with liquids (drinks, perspiration etc.). This may cause corrosion.
- The machine is designed for use by adults and children should not be allowed to play with it. Children at play behave unpredictably and dangerous situations may occur for which the manufacturer cannot be held liable. If, in spite of this, children are allowed to use the equipment, ensure that they are instructed in its proper use and supervised accordingly.
- The crosstrainer complies with the DIN EN 957-1/-9, class HB. It is therefore unsuitable for therapeutic use.
- A slight production of noise at the bearing of the centrifugal mass is due to the construction and has no negative effect upon operation. Possibly occurring noise during reverse pedalling result from engineering and are absolutely safe.

- Do not use corrosive or abrasive materials to clean the equipment. Ensure that such materials are not allowed to pollute the environment.
- The crosstrainer has a magnetic brake system.
- To operate correctly, the pulse function requires a minimum voltage of 2,7 volts (only for computers working with batteries).
- The equipment is dependent of revolutions per minute.
- Please ensure that liquids or perspiration never enter the machine or the electronics.
- Before use, always check all screws and plug-in connections as well as respective safety devices fit correctly.
- Always wear suitable shoes when using.
- All electric appliances emit electromagnetic radiation when in operation. Please do not leave especially radiation-intensive appliances (e.g. mobile telephones) directly next to the cockpit or the electronic controlsystem as otherwise values displayed might be distorted (e.g. pulse measurement).

Instructions for Assembly

- Ensure that you have received all the parts required (see check list) and that they are undamaged. Should you have any cause for complaint, please contact KETTLER Parts and Service Dept.
- Before assembling the equipment, study the drawings carefully and carry out the operations in the order shown by the diagrams. The correct sequence is given in capital letters.
- The equipment must be assembled with due care by an adult person. If in doubt call upon the help of a second person, if possible technically talented.
- Please note that there is **always** a danger of injury when working with tools or doing manual work. Therefore please be careful when assembling this machine.

- Ensure that your working area is free of possible sources of danger, for example don't leave any tools lying around. Always dispose packaging material in such a way that it may not cause any danger. There is always a **risk of suffocation** if children play with plastic bags!
- The fastening material required for each assembly step is shown in the diagram inset. Use the fastening material exactly as instructed. The required tools are supplied with the equipment.
- Bolt all the parts together loosely at first, and check that they
- have been assembled correctly. Tighten the locknuts by hand until resistance is felt, then use spanner to finally tighten nuts completely against resistance (locking device). Then check that all screw connections have been tightened firmly. Attention: once locknuts have been unscrewed they no longer function correctly (the locking device is destroyed), and must be replaced.
- For technical reasons, we reserve the right to carry out preliminary assembly work (e.g. addition of tubing plugs).

List of spare parts page 10-12

When ordering spare parts, always state the full article number, spare-partnumber, the quantity required and the S/N of the product (see handling).


Example order: Art. no. 07852-690 / spare-part no. 91170500 / 2 pieces / control number/ S/N Please keep original packaging of this article, so that it may be used for transport at a later date, if necessary.

Important: spare part prices do not include fastening material; if fastening material (bolts, nuts, washers etc.) is required, this

should be clearly stated on the order by adding the words "with fastening material".


KETTLER International Inc.
P. B. 2747 · Virginia Beach · VA 23450-2747 USA http://www.kettlerusa.com


Checklist (contents of packaging)





Checklist (contents of packaging)


| Checkinsi (co. | | | |
|----------------|------------|-----|--|
| | | 2/2 | |
| | | 2 | |
| | ø42 | 2 | |
| | M6 | 2 | |
| <u>(0)</u> | ø25x8,4 | 4 | |
| 0 | ø25x10,4 | 4 | |
| 0 | ø21x8,4 | 2 | |
| 0 | ø12,5x6,4 | 2 | |
| | M10×105 | 2 | |
| | M6x50 | 2 | |
| | M8×20 | 6 | |
| () | M5x20 | 2 | |
| | ø22,2x27,5 | 2 | |
| | M10 | 2 | |
| | | 8 | |
















6





Handling




For products with power supply: **Attention!** Only use with original power unit as supplied, or with original KETTLER spare part (see spare part list). **Otherwis this may result in damage.**


Handling







Handling




PRI: 110V ≈ 50Hz 50mA SEC: 6V = 500mA 3VA





Attention! Only use with 6V original power supply. Otherwise this may result in damage.





When ordering spare parts, always state the full article number, spare-partnumber, the quantity required and the S/N of the product.

Spare parts order

| | Crosstrainer MONDEO | | 07852-690 |
|------|---|-----|----------------|
| Pos- | | | |
| Nr. | Description | Qty | Spare Part Nr. |
| 1 | Base Frame (07852-690) | 1 | 94315235 |
| 2 | Adapter Ring | 1 | 70128492 |
| 3 | Ski Pole Bearing 6203-ZZ | 4 | 33100038 |
| 4 | Drive Axle 17x114.5 | 1 | 11300055 |
| 5 | "C" Clip 17mm (17 DIN 471) | 3 | 10709021 |
| 6 | "C" Clip 44mm (I 40 DIN 472) | 3 | 10709024 |
| 7 | Frame Crossmembers | 2 | 91111287-20 |
| 8 | Right Transport Castor | 1 | 91170387 |
| 9 | Left Transport Castor | 1 | 91170388 |
| 10 | Floor Levelers | 2 | 91170500 |
| 11 | Underside Plate for Frame Cross Member | 2 | 97200256 |
| 12 | Fiber Paper Gasket for Frame Cross Member | 2 | 34010120 |
| 13 | Magnetic P/U Wire 375mm | 1 | 67000690 |
| 14 | Cable Clamp 3x5.6 | 1 | 67000088 |
| 15 | Metal Bracket for Flywheel (BD 1399) | 1 | 1701399A |
| 16 | Flywheel Resistance Magnet | 1 | 94313567 |
| 17 | Flywheel Magnet Segment | 3 | 67000170 |
| 18 | Set Spindle | 1 | 97201389 |

Spare parts order

| Pos- | Crosstrainer MONDEO | | 07852-690 |
|----------|--|-----|----------------------|
| Nr. | Description | Qty | Spare Part Nr. |
| 19 | Spring for Magnet Tension 1.6mm | 1 | 25605891 |
| 20 | Idler Pulley w/ Bearings 6300-ZZ | 1 | 94313101 |
| 21 | distanz sleeve ø22.2x2x5 mm | 1 | 97201470 |
| 22 | Spring for Belt Tension 3.5mm | 1 | 25635052 |
| 23 | Flywheel + Pos. 25 + 26 | 1 | 91140379 |
| 24 25 | Bearing for Drive Axle 6203-ZZ | 2 | 33100023 33100017 |
| 26 | Bearing for Flywheel 6203-ZZ C3 (Pos. 23) Bearing 6005-ZZ (w/o fig.) (Pos. 23) | 1 | 33100017 |
| 27 | M-05 Motor | i | 67000797 |
| 28 | Adapter Wire 900mm | 1 | 67000799 |
| 29 | Lower Lead Wire 900mm | 2 | 67000795 |
| 30 | Pulley | 1 | 43004071 |
| 31 | Right Drive Disc (red) | 1 | 94315240 |
| 32 | Left Drive Disc (red) | 1 | 94315243 |
| 33 | Right Drive Disc Shaft 20x120.5 | 1 | 10900091 |
| 34 | Left Drive Disc Shaft 20x120.5 | 1 | 10900092 |
| 35 | Right Side Lower Main Shroud | 1 | 70128704 |
| 36 | Left Side Lower Main Shroud | 1 | 70128705 |
| 37 | Right Side Upper Main Shroud | 1 | 70128710 |
| 38 | Left Side Upper Main Shroud | 1 | 70128711 |
| 39 | Drive Disc Cap | 2 | 94315477 |
| 40 | Mast Cover | 1 | 70128569 |
| 41 42 | Sleeve for Main Frame Skis | 1 2 | 70128698 |
| 43 | Bearings for Skis 2203 RS2 | 2 | 94315247 33100047 |
| 44 | Mast | 1 | 94315268 |
| 45 | Lower Center Handlebar w/ Grip and Handpulse | 1 | 94315490 |
| 46 | Upper Center Handlebar w/ Grip | 1 | 94315275 |
| 47 | Grip for Lower Center Handlebar 27.5x3x445mm | 2 | 10118105 |
| 48 | Hand Pulse Sensors WP 1007-5C | 1 | 67000658 |
| 49 | Front Computer Housing | 1 | 70128730 |
| 50 | Rear Computer Housing | 1 | 70128731 |
| 51 | Computer SM3200-8 (mile, °F) | 1 | 94315484 |
| 52 | Ear Lobe Clip Heart Rate Monitor | 1 | 67000653 |
| 53 | Front Upper Mast Cover | 1 | 70128728 |
| 54 | Rear Upper Mast Cover | 1 | 70128729 |
| 55 | Right Ski Pole | 1 | 94315437 |
| 56 57 | Left Ski Pole Spacer Sleeve 10x1.9x13mm | 1 | 94315436 97200445 |
| 58 | Ski Pole Grips 27.5x3x680mm | 2 | 10118034 |
| 59 | Lower Ski Pole Bearing 6200-ZZ | 4 | 33100036 |
| 60 | Front Bottom Ski Pole Cover | 2 | 70128413 |
| 61 | Rear Bottom Ski Pole Cover | 2 | 70128414 |
| 63 | Center Rear Ski Pole Cover | 2 | 70128412 |
| 64 | Center Front Ski Pole Cover | 2 | <i>7</i> 0128411 |
| 65 | Right Foot Plate | 1 | 70128702 |
| 66 | Left Foot Plate | 1 | 70128703 |
| 67 | Right Front Ski Cover | 2 | 70128696 |
| 68 | Left Front Ski Cover | 2 | <i>7</i> 0128697 |
| 69 | Water Bottle Holder | 1 | 70190051 |
| 70 | Water Bottle | 1 | 70190041 |
| 71 | Spacer Sleeve 22.2x2x27.5mm | 2 | 97201463 |
| 72 73 | Distance Tube (3126) Ski Pala Tan Can Part 1/4011) | 2 | 70133275 |
| 73 74 | Ski Pole Top Cap Part 1(4011) Ski Pole Top Cap Part 2(4013) | 2 | 70121517 70121518 |
| 75 75 | Plug for 42mm | 2 | 10100079 |
| 76 | Foot Plate Adjuster Cap m6 | 2 | 10104006 |
| 77 77 | Drive Belt 1651 PJ6 | 1 | 67005127 |
| 78 | Lower Ski Pole Sleeve 20x4.5x59mm | 2 | 97201447 |
| 79 | Power Supply | 1 | 67000798 |
| 80 | Plug Receptacle | 1 | 94315283 |
| 81 | Soft-Grip 27.5x405mm | 1 | 10118104 |
| 82 | Plate spring B 31.5 GR 1 X 1.2 | 3 | 10600004 |
| | | | |

